

# IMPACT 800 series

On-ear wired USB headset

User Guide

# Contents

Welcome	3
Package contents	4
IMPACT 800 at a glance	5
leadset at a glance	5 5
How to wear the headset	9
Adjusting and wearing the headset Positioning the microphone	9 9
How to connect	10
A Connecting directly to your computer	10
B Connecting to your mobile device	11
Installing the EPOS Connect desktop app Changing audio settings - Microsoft® Windows	12 12
How to use - basic functions	13
Changing the volume	13
Muting the headset's microphone	15
Using Active Noise Cancellation – ANC version only	16
Using TalkThrough – ANC version only	18
Making calls using the headset	19
Making a call	19
Accepting / rejecting a call	20
Putting a call on hold (pause)	22
Ending a cail Managing multiple calls	22 23
Using Microsoft <sup>®</sup> Teams - IMPACT 860T / 860T ANC only	25
Invoking Microsoft® Teams	
Raising hand in a Teams meeting	
Checking Teams Notifications	27
Listening to media	28
Controlling via the wear detection sensor	
Controlling via the button	29

Good to know	
Activating / deactivating sensor functions	
Adjusting the Sidetone	
Changing the voice prompts' language	
Adjusting sounds and notifications	
Enabling / disabling an Audio Limiter	
Maintaining & updating products	
Cleaning the products	
Transporting and storing the products	
Replacing the ear pads	
Updating the firmware	
If a problem occurs	

### Trademarks

USB Type-C $^{\circ}$  and USB-C $^{\circ}$  are trademarks of USB Implementers Forum. All other trademarks are the property of their respective owners.

# Welcome

# Be the best in the New Open Office

The next generation headset for desk workers in the New Open Office. Increase efficiency by 40%\* by improving reaction time whilst multi-tasking to maintain accuracy with EPOS BrainAdapt<sup>™</sup>, and industry-leading voice pickup by EPOS AI<sup>™</sup>.

Be heard no matter the level of background noise, and get super wideband audio for natural sound. Enjoy total ease of use with intuitive controls and smart features. Experience all-day wearing comfort with a lightweight design, soft cushions and headband padding.

Certified for leading UC providers and meets the Microsoft Teams Open Office specifications. Stay focused during calls thanks to technology that boosts the clarity of incoming speech while the 360 busylights signal to colleagues when you're unavailable

\*EPOS BrainAdapt™ Dual Task Study

### Key benefits & features

Superior EPOS sound

Super wideband audio and stereo sound deliver clear speech in noisy open offices

EPOS BrainAdapt<sup>™</sup> technology Better focus for both sides via ANC, EPOS Al<sup>™</sup>, and industry-leading voice pickup

Adaptive digital microphones Adaptive beamforming microphones deliver industry-leading voice pickup

TalkThrough

Communicate easily with in-office colleagues without removing the headset

#### 360-degree busylight

Intuitive busylight clearly signals when you're on call and not to be disturbed

#### Smart features

Initiate, end, and mute calls by moving the boom arm or taking the headset on/ off

Convenient carry pouch

Carry the headset easily between your work and home office

Image: Section Section

# Package contents

### IMPACT 860 ANC | IMPACT 860 IMPACT 860T ANC | IMPACT 860T: Microsoft Teams version



# IMPACT 800 at a glance

## lcons at a glance



### Headset at a glance



\*Microsoft Teams: IMPACT 860T / 860T ANC only



\*ANC: IMPACT 860 ANC / 860T ANC only

### Headset LEDs at a glance



You can change some of the LED settings via EPOS Connect.

### **Busylight LED** Meaning Incoming call: if you do not Ö wear the headset Active call ۲ Call on hold \* Connected to Teams Connecting to Teams **.** . Teams notification

Mute LED at boom arm		Meaning
*	*	Microphone muted
	* * * * *	Talking while microphone is muted

### Headset buttons at a glance

Hook & Teams* button	Press	Function	Page
8		Accepts a call	20
		Ends a call	22
		2 calls: Answers incoming & ends active call	23
		2 calls: Ends active and keeps 2nd call on hold	24
		Invokes Microsoft Teams*	25
	2x	Puts an active call on hold (pause) / unholds call	20
		2 calls: Answers incoming & puts active call on hold	23
/ / /		2 calls: Toggles between two calls	24
*variant dependent: IMPACT 860T / 860T ANC only:		Raises/lowers hand in a Teams meeting* upon release	26
	2s	Rejects a call	22
ANC button**	Press	Function	Page
	2s	Switches ANC on / off	16

Switches TalkThrough on/off (only if ANC is switched on)

\* IMPACT 860T / 860T ANC only

\*\* IMPACT 860 ANC / 860T ANC only

18

Multi-function slider	Press	Function	Page
		Mutes / unmutes the microphone	15
		Starts / pauses audio playback	28
	+	Increases the volume (press or press and hold)	13
		Skips to the next track	28
		Skips to the previous track	28

# How to wear the headset

## Adjusting and wearing the headset

For good sound quality and best possible wearing comfort:

- > Adjust the headset so that the ear pads rest comfortably on your ears.
- Rotate the boom arm to change wearing side. Swap the stereo channels via EPOS Connect.



### Positioning the microphone

> Bend and rotate the boom arm so that the microphone is about 0.8" (2 cm) from the corner of your mouth for best call quality.



# How to connect

You can connect the headset either:

- A to your computer or
- B to your mobile device

You can completely remove and reattach the USB-A adapter from the USB cable. To remove the USB-A adapter:

- > Disconnect the adapter from the USB-C plug.
- > Push the USB plug through the small opening at the end of the rubber holder.

### A Connecting directly to your computer

- > Attach or detach the USB-A adapter.
- > Plug the headset into a USB-C or USB-A port of your computer. The headset switches on and off with your computer.



To disconnect the headset:

> Pull the plug out of the USB port.

# B Connecting to your mobile device

The following functions depend on the connected mobile device and apps and may not work for all of them.

- > Detach the USB-A adapter.
- > Plug the headset into the USB-C port of your mobile device. The headset switches on and off with your mobile device.



To disconnect the headset:

> Pull the plug out of the USB port.

# Installing the EPOS Connect desktop app

The free EPOS Connect software allows you to configure and update your headset and offers additional settings.

- > Download the software from eposaudio.com/connect.
- Install the software. You need administrator rights on your computer if necessary, contact your IT department.



## Changing audio settings - Microsoft® Windows

Windows usually changes the Audio settings automatically if you connect a new headset. If the headset is connected but you hear no sound:

- > Right-click the Audio icon.
- > Select under output IMPACT 8xO as speaker.
- > Select under input IMPACT 8xO as microphone.





# How to use - basic functions



### CAUTION

Risk of hearing damage!

Listening at high volume levels for long periods can lead to permanent hearing defects.

- > Set the volume on your connected device to a low level before putting on the headset.
- > Do not continuously expose yourself to high volumes.

## Changing the volume

You can adjust three independent volume settings for the headset:



i

Move the Multi-function slider to + or - to increase or reduce the volume.
 You hear a double beep for maximum or minimum volume.



Alternatively, you can adjust the volume for calls and media streaming on your connected device.

### Adjusting the headset's microphone volume for softphones

- Initiate a call on your connected device to someone who will help you find the correct volume setting for your microphone.
- > Change the microphone volume in your softphone application and/or in your computer's audio application.



## Muting the headset's microphone

- > A Move the boom arm up to mute (you feel a slight resistance) or down to unmute the microphone\*. OR
- B Tap the Multi-function slider to mute or unmute the microphone. The Mute LED lights up red while muted.



The microphone will also be muted by taking the headset off and unmuted when you put it on again.\*

The LED flashes red, if you are talking while the microphone is muted\*.  $| \mathbf{x} | \mathbf{x} | \mathbf{x} | \mathbf{x} |$ 

\*This function could be activated/deactivated via EPOS Connect.

(i)

## Using Active Noise Cancellation - ANC version only

The IMPACT 860 ANC / 860T ANC provides attenuation of ambient noise using Active Noise Cancellation (ANC) technology. Special microphones reduce background noise, such as keyboard sounds or chats from colleagues in an open office environment.



If you are in a noisy environment but would like to have your own quiet space, you can use the headset itself, disconnected from any device, and simply benefit from ANC.

### Switching ANC on / off

 Press the ANC button for 2 seconds or use EPOS Connect to activate or deactivate ANC.



### Using and adjusting ANC

The headset is equipped with **Adaptive ANC** and responses to the surrounding noise level. The built in ANC responds to the surrounding noise level to activate just as much ANC as is needed at a given time. This decreases the feeling of occlusion for situations where it is not needed.

The additional **ANC Level slider** allows you to set your individual ANC intensity (when adaptive mode is deselected).

Via EPOS Connect you can:



> Choose or adjust your ANC mode.

Available Noise Control settings:

Adaptive ANC	Adjusts the ANC intensity automatically
ANC Level	> Change the ANC intensity to your preferred level.

# Using TalkThrough - ANC version only

TalkThrough allows you to communicate with your colleagues without having to remove the headset, when ANC is switched on. Media playback will be paused or muted.



### Switching TalkThrough on / off

- > Activate ANC (see former pages).
- > Tap the ANC button to activate or deactivate TalkThrough.



### Adjusting the TalkThrough intensity



Via EPOS Connect you can:

 Change the TalkThrough intensity via the Noise Control settings.



# Making calls using the headset

The following functions depend on the connected device.

To make calls via the computer:

> Install a softphone (VoIP Software) or ask your admin for support.

The Busylight LED lights up red as long as you are in a call or there is a call on hold.



# Making a call

Initiate the call on your connected device.
 The Busylight LED lights up red as long as you are in a call.



# Accepting / rejecting a call

There are several ways to accept an incoming call.

### Indications of an incoming call

When you receive a call, you hear a ring tone. If you do not wear the headset, the flashing Busylight LED indicates the incoming call.



### Accepting a call

You can accept a call in three different ways:

- > A Tap the Hook button. OR
- > B Move the boom arm down.\* OR
- > C Put the headset on if not worn\*. The headset is equipped with a wear detection sensor that registers when the headset is worn.



\* B + C: This function could be activated/deactivated via EPOS Connect.

### Rejecting a call

> Press the Hook button for 2 seconds.



# Putting a call on hold (pause)

> Double tap the Hook button to put a call on hold or unhold the call.



# Ending a call

- > Tap the Hook button to end the call. OR
- > End the call via your connected device.



## Managing multiple calls

Two calls can be managed simultaneously. If you receive a call during an active call, a knock on tone will be played.



### Toggle between calls / end active call



# Using Microsoft<sup>®</sup> Teams – IMPACT 860T / 860T ANC only

To use Microsoft Teams with the headset:

> Connect the headset to your computer - see page 10. If Microsoft Teams is already running on your computer, the Teams LED lights up purple. Otherwise install and run Microsoft Teams.



## Invoking Microsoft® Teams

- > A Tap the Hook & Teams button. OR
- > B Open Microsoft Teams on your connected device.



## Raising hand in a Teams meeting

> Press the Hook & Teams button for 1 second and release it to raise or lower hand.



# Checking Teams Notifications

The LED pulses purple to indicate:

- Meeting Join Notification
- Voice Mail Notification
- Missed Call Notification



To check these Notifications on your screen:

> Tap the Hook & Teams button.



# Listening to media

> Play the media on your connected device.



D If you receive and accept a call, media reproduction is paused and resumed after the call – if supported by the connected device.

### Controlling via the wear detection sensor

The headset is equipped with a wear detection sensor that registers whether it is on the head or not.

- Take the headset off.
  Media reproduction is paused.
- > Put the headset on.

Media reproduction resumes, if media was paused via the wear detection sensor.



This function could be activated/deactivated via EPOS Connect.

## Controlling via the button

The following functions are device dependent.



# Good to know

# Activating / deactivating sensor functions

The headset is equipped with a wear detection sensor that registers whether it is on the head or not. A second sensor registers the boom arm position.

#### Via EPOS Connect you can:

> Activate or deactivate Smart Pause functions.



#### Available settings:

Answer Call	Accepts a call when you put on the headset		
	Accepts a call if you move the boom arm down		
Mute	Mutes the microphone when headset is removed during a call and unmutes when put on again		
	Mutes the microphone if you move the boom arm up		
Play/pause	Pauses Media playback when you remove the headset and continues when you put it on again		

## Adjusting the Sidetone

Sidetone is the audible feedback of your own voice during a phone call.

> Change the strength for the Sidetone in EPOS Connect.



## Changing the voice prompts' language

 Choose the corresponding voice prompts' language from the list in EPOS Connect (English by default).



# Adjusting sounds and notifications

> Change the sounds and notification in EPOS Connect.



Tone & voice prompts	Turns on/off prompts in the headset
Voice prompt language	Changes language of voice prompts in the headset
No voice prompts during call	Turns on/off non-essential voice prompts during a call
Mute interval	Selects the notification interval when the headset is muted
Talk while muted	Turns on/off the additional flashing of the boom arm LED: The LED generally lights up red while muted. If you activate this function, the LED flashes as soon as you start speaking as an additional reminder.

# Enabling / disabling an Audio Limiter

> Choose an Audio Limiter in EPOS Connect.



EU/US limiter	Activates limiter: max. 90 dB; compliant with Directive 2003/10/EC
AU limiter	Activates limiter: max. 85 dB; compliant with Directive AS/ACIF G616:2006

# Maintaining & updating products

## Cleaning the products

#### WARNING

Liquids can damage the electronics of the product!

Liquids entering the housing of the device can cause a short circuit and damage the electronics.

- > Keep all liquids away from the product.
- > Do not use any cleansing agents or solvents.
- > Use a dry cloth to clean the product only.



## Transporting and storing the products

> Keep the products in a clean and dry environment.

To avoid nicks or scratches on the headset:

> Store the headset in the case when not in use or when carrying it around. Lift the boom arm and twist in the ear cup(s).



## Replacing the ear pads

For hygienic reasons, replace the ear pads. Spare ear pads are available from your EPOS partner.

- 1 Lift the boom arm and twist in the ear cups.
- 2 Grasp the edge of the ear pad behind the ear cup and peel it up and away from the ear cup.
- 3 Slide the edge of the new ear pad into the small recess. Carefully rotate the ear pad anti-clockwise until it is fully attached.



# Updating the firmware

You can update the firmware of your headset by using the free EPOS Connect software (see page 12).

- > Connect the headset to your computer.
- > Start EPOS Connect.

If there is a new firmware available the software will guide you through the update process.



# If a problem occurs...



Many functions can be activated/deactivated or adjusted in EPOS Connect:

> Adjust the settings.

Problem	Possible cause	Solution	P	age
No audio signal or drop outs	Volume adjusted too low	Increase the volum during a call or me on your connected	e on the headset dia streaming or I device.	13
	USB plug not fully inserted	Insert the plug aga	in.	11
	Other audio source selected	Select EPOS IMPA Audio settings.	CT 8xO in the	12
Microsoft Teams button does not work	Microsoft Teams not running on your computer	Open Microsoft Tea computer.	ams on your	-
Beeps instead of voice prompts	Voice prompts disabled	Enable voice prom Connect.	pts via EPOS	32
Sound alerts during calls disturbing	Voice prompts or tones during calls enabled	Disable voice prom calls in EPOS Conr	pts / tones during nect.	32
Voice prompts too loud or quiet	Volume for voice prompts adjusted too high or low	Adjust the volume	in idle mode.	13
Stereo sound mirrored	Headset wearing side swapped	Change the wearin EPOS Connect.	g side setting via	-
You hear your own voice too loud	Sidetone adjusted too high	Change the sideton EPOS Connect.	ne setting via	31
Headset does not respond to wear	Wear detection sensor deactivated	Activate wear detection EPOS Connect.	ction sensor via	30
detection sensor gestures		Unplug and plug in to re-start headset	the headset again	-
Microsoft Teams does not work	Microsoft Teams or connection to the app disturbed	Re-start Microsoft computer.	Teams on your	-
Headset does not react to any button press	Software or hardware problems	Use EPOS Connec headset.	t to reset the	-

If a problem occurs that is not listed here or if the problem cannot be solved with the proposed solutions, please contact your local EPOS partner for assistance.

To find an EPOS partner in your country, search at eposaudio.com

eposaudio.com/impact800





# DSEA A/S

Kongebakken 9, DK-2765 Smørum, Denmark eposaudio.com

12/23, AO1